






Use the below products when utilising a DIY system to paint your caravan, motorhome or horsefloat.



WHAT YOU WILL NEED ✓

-  **Altex C-50 Surface Cleaner**
-  **Altex Thinning Solvent #22**
-  **Altex Epoxy 1:1 Spot Filler**
-  **Altex Polyurethane Undercoat**
-  **Altex Elite 321 Brushing Polyurethane**
- Empty tins and mixing stick
- Scotch-Brite - fine grade
- Masking tape
- Sandpaper - High quality grade (We recommend: 3M Gold series or similar)
- Paint roller tray
- Paint roller and sleeves
- Paint brushes - a high quality, fine tip brush is important



History. Service.
Innovation.



Get your very own **Shop Card** and enjoy the perks of saving big with exclusive discounts!

Apply in store or online: www.thealtexpaintshop.com

THE ALTEX PAINT SHOP

AUCKLAND

68 Patiki Road, Avondale **Ph: 09 828 3422**

TAURANGA

91-111 Oropi Road, Greerton **Ph: 07 541 1955**

NELSON

79 Vickerman Street, Port Nelson **Ph: 03 546 8375**

CHRISTCHURCH

10D Craft Place, Middleton **Ph: 03 335 0673**

DUNEDIN

4 Mason Street, City Centre **Ph: 03 474 1890**



TECHNICAL HELPLINE

We have a great Technical team available who will happily discuss all your painting requirements with practical advice. Our Factory Shop staff are dedicated to making sure you receive top service and information.

0800 258 390

www.thealtexpaintshop.co.nz



THE ALTEX PAINT SHOP

CARAVAN MOTORHOME & HORSEFLOAT MAINTENANCE



Get your project started and finished with hard wearing, heavy duty coatings to protect your assets against the elements.

Transform your vehicle with ease!



CARAVAN MOTORHOME & HORSEFLOAT MAINTENANCE

The Altex Paint Shop have extensive experience coating Fibreglass, Gelcoat & GRP Substrates.

We have carefully designed a system and complementing products to ensure your caravan, motorhome or horsefloat has long lasting protection against the elements and the uncompromising Kiwi environment.

Altex products are simple and easy to use boasting the following:

FEATURES



- ✓ Ease of use
- ✓ 3 stage application
- ✓ Simple brush/roller application
- ✓ High grade finish
- ✓ Long service life
- ✓ The approximate project time is 48 hours (for exterior of double horse float or small caravan)

PROCESS

Follow the below process for a DIY system to paint your caravan, motorhome or horsefloat like a professional.

1

SURFACE PREPARATION



Water blast the surface area to be painted

Wipe down with specialized **C50 SURFACE CLEANER**

Filling can be done with **EPOXY SPOT FILLER** to get a smooth surface for painting.

Sand and remove dust

2

PRIMING, FILLING & UNDERCOATING



Exposed Aluminum Areas

Before undercoating use **EPOXY ALUMINIUM PRIMER** to prevent corrosion and help undercoat adhesion.

Undercoat can be done with either:

EPOXY BARRIER UNDERCOAT - A thicker paint that is cold weather friendly. Great if you plan on that weekend project and undercoats will be sealed over within days.

or

POLYURETHANE UNDERCOAT - Ideal for longer periods between undercoating layers and top coating.

3

FINISH COATING



Finish with two coats of **ELITE 321 BRUSHING POLYURETHANE** for longevity of finished look and a glossy full bodied colour.

A video demonstration of ELITE 321 being applied is online. For exact painting process and tech specs visits our web site or if you want help planning your project talk to us today!

